



E I C H H O L T Z

111201 CONSOLE TABLE CURTIS

ASSEMBLY INSTRUCTION

PARTS

2x

4x




16x

1x

1x

4x

1x



(A)

(B)

(C)


(D)

(E)


(F)

(G)

1



3



4

