




E I C H H O L T Z


109688 FOLDING SCREEN MADEMOISELLE GABRIELLE

INSTRUCTION


- 1** Remove all the screws and take the carton from the crate.




- 2** Carefully cut the tape in the length of the cartons with a knife blade not longer than 2,5 cm to avoid damage to the folding screen. Remove the carton and plastic.



- 3** Now, open the plastic and stand the article vertically with the ball feet on the ground.



- 4** Extend the screen and remove the protection material between the panels.



- 5** If there is a balance issue, adjust the ball feet by turning the ball feet.

